



680 Chair Arm Replacement

Applies to Models:
680

Special Tools:
Soft faced mallet

Language of origin: English



To install chair arms...

- A) Use soft faced mallet to remove current arm.
- B) Insert both sides of new arm into chair base.
- C) Cover new arm with cloth.
- D) Use soft faced mallet to tap arm in place.

MA9700

TP200 Rev. A