



Tools required:  
#2 Phillips Drive Screw driver or #2 Square bit drive

Parts Included:  
(1) Med Drawer Assembly  
(4) 1/4-20 x 5/8" Long Phillips Drive Pan Head Machine Screws  
(2) Keys

**I** Using the (4) screws, attach drawer to underside of worksurface (see drawing for drawer placement) using the predrilled holes.

