



Tools required:
Phillips head screwdriver or #2 Square drive bit

Parts Included:
(4) #10-24 x 1 1/4" Long Pan Head Phillips Drive Self Locking PHMS
(1) Barcode Holder
(2) Velcro strips

I Align Barcode Holder to specified hole placements (see Fig. A).

Secure to worksurface (from underside) using (4) screws.

Fig. A

