



Tools required:
Phillips head screwdriver or #2 Square drive bit

Parts Included:
(1) Counterweight Plate
(4) 1/4-20 x 1" Long Button Head Cap Screws
(4) 1/4" SAE Flat Washers

I Align Counterweight Plate to specified hole placements (see pict. A).

Secure to bottom of base with (4) 1/4" SAE Flat Washers and (4) 1/4-20 x 1" Long Button Head screws.

